

How to mount the Touch into the IP65 case

Octalarm-TOUCH | *Octalarm-TOUCH pro*

Because of the modification of the IP65 cabinet by Adésys, a quick and simple installation in only 7 steps is possible. The modification consists of a mounting rail and supplied cover plate (and associated screws).

Easy assembly in just 7 steps

1. Open the cabinet and unscrew the 4 sliders from the cover plate.
2. Take the black cover plate out of the cabinet by slightly counterpressing the clips and pulling the plate forwards.
3. Remove the two lower screws (from the point of view when the Adésys logo is on the top right cabinet).
4. Slide the Octalarm-Touch (not supplied) with the appropriate recesses on the back of the alarm device, over the top screws.
5. Open the Octalarm-Touch cover and screw back the two screws removed in step 3.
6. Connect all required cables. Use the front notches of the IP65 cabinet to your own liking.
7. Refit the cover plate and screw in the four screws.