

How to optimally use your dialler

Octalarm-TOUCH PRO | ARA - PRO NEXT



Create a free account at **portal.octalarm.com**

- ✓ Remote setup and management
- View current status alarms
- Installer can provide remote support
- Possible to use app "Adesys Alarm"

Arranged in 4 steps

- 1. Go to https://portal.octalarm.com
- 2. Create an account and log in
- 3. In the 'Devices' screen, press '+'
- 4. Enter the serial number and the pairing code These can be found in the dialler under 'Settings' | 'System information



Download the free app 'Adésys Alarm'

- Access your dialler(s) literally from your pocket
- High priority alarms always on your mind
- Location alarm immediately visible via alarm app

Set push alarm in 5 steps

- 1. Download 'Adésys Alarm' app from the Playstore (Android) of Appstore (iOS)
- 2. Log in with your portal account and give permission to receive notifications
- 3. In the dialler, add the Email address with which the contact is known in portal.octalarm.com to the contact person
- 4. In the dialler, add a push to the relevant call list with an Email address with which the contact is known in the portal.octalarm.com
- 5. Link the call list to the desired alarm in the dialler

To use the app and allow for remote setup, the web portal must be enabled on the alarm dialler.



Activate Octalarm Connect

- Reliable GSM and/or VoIP calling connection set up in one go
 - Fixed price per month (flat fee): *Touch Pro contact-controlled*
 - GSM and VoIP: € 14,95 excl. VAT
 - VoIP only: € 8,95 excl. VAT

Touch Pro network controlled / ARA-Pro Next

- Connect XL (GSM and VoIP): € 19,95 excl. VAT
- VoIP only XL: € 13,95 excl. VAT
- ✓ 24/7 secured duplicate servers

Octalarm Connect activated in 8 steps

- 1. Connect the dialler with the supplied UTP cable to the internet
- 2. Ask the customer for:

Email address*: info@companyname.uk

VAT number: GB123456789

- * If the E-mail address is from an accounting program, you should take into account that this program can handle verification. You can check this with the supplier of your accounting program.
- 3. Start up the alarm dialler and start configuration
- 4. Choose 'yes' in the Octalarm Connect XL wizard
- 5. Enter the customer's Email address

The customer then receives an activation Email. Ask the customer to activate the subscription via the activation Email:

- 6. Enter the customer's company details and VAT no
- 7. Select the desired subscription
- 8. Take payment by credit card (worldwide), iDeal (the Netherlands), Bancontact (Belgium) or Giropay (Germany)

The SIM card (GSM) and/or the VoIP connection are now active. The payment is collected monthly by direct debit from the end customer. A maximum of 2 days after payment, the invoice will be made available in the company account on the portal and e-mailed to the specified Email address.